

Audio Express Manual Addendum

OVERVIEW

This sheet provides late-breaking information about your Audio Express audio interface not covered in the enclosed *Audio Express User Guide*.

SWITCHING BETWEEN FIREWIRE AND USB

Most of the time, the Audio Express can detect whether a FireWire or a USB cable is connected to it, and it will automatically switch to FireWire operation or USB operation accordingly. Some FireWire or USB ports that do not provide bus power can not be automatically detected by the Audio Express, and you may need to switch the device to FireWire mode or USB mode manually:

To switch to	Press and hold this knob while turning on the Audio Express
FireWire	LINE 3 knob
USB	LINE 4 knob

When the Audio Express switches to FireWire operation, it displays *F* on the front panel LEDs. When it switches to USB operation, it displays *U* on the front panel LEDs.

CONNECTING OTHER MOTU FIREWIRE AUDIO INTERFACES

On page 26, the Audio Express User Guide for Windows incorrectly states that up to four MOTU FireWire audio interfaces can be connected to the computer. At this time, the MOTU FireWire audio driver for Windows supports up to three FireWire audio interfaces, not four.

USING 'ENABLE PEDAL' UNDER WINDOWS

On page 32, the Audio Express User Guide for Windows incorrectly states that the Enable Pedal option in the MOTU Audio Console program is not available for the Audio Express. The Audio Express's pedal input can be used to trigger software functions such as punching in and out of record mode or starting and stopping playback.

Enable the pedal input by selecting the Enable Pedal option in MOTU Audio Console. Then use the Set buttons to choose which keyboard shortcuts will be triggered by the pedal up and pedal down actions.

For example, if a DAW program uses the space bar to start playback and the return key to stop playback, you could set the pedal down action to space bar and the pedal up action to return. Then the sequence will play while the pedal is pressed and held down, and it will stop when the pedal is released.

MANUAL ERROR

On page 52 of the Mac User Guide and page 48 of the Windows User Guide, there is an incorrect reference to "Audio Express-based effects processing (EQ, compression or reverb)". There is no on-board effects processing in the Audio Express digital mixer: only mixing and routing.